

Clean & Care Instructions



GATEWAY
office furniture

Avoid Abrasive cleaners such as: dry powders, acids, graffiti cleaner, steel wool and scrubbing pads as these may cause dulling to finishes, reactions with plastics, and scratch marks. Using the incorrect cleaner or cloth can result in marring of the acrylic or fabric.

Acrylic: Always soft, non-abrasive cloth (not paper towel unless it is soft, not textured). Cleaners tested on the product have been Clorox wipes, Hand Sanitizer (with Isopropyl Alcohol (70%) or Hydrogen Peroxide) and wiped clean with the non-abrasive cloth as mentioned before to remove excess product.

Recommended Cleaning Steps

- Apply appropriate cleaning solution (see recommended cleaning solutions above) to a piece of white, lint free cloth. Use a hand spray applicator, do not oversoak.
- If required, renew the cleaning cloth. Repeat process until there is no further transfer of the dirt to the cloth
- Use a clean cloth or sponge soaked in water to remove any residue.
- Allow treated surface to air dry

****** Cleaning information is offered for general guidance and is not a guarantee. The use of certain cleaning agents can be harmful to the surface appearance and lifespan of a product. Gateway assumes no responsibility for damage to a product resulting from lack of cleaning, improper cleaning or the misuse of cleaning agents. Certain clothing and accessory dyes (such as those used on denim jeans) may migrate to materials and cause permanent damage. Gateway cannot be held responsible for dye transfer caused by external contaminants.