

STEP 5:

STEP 6:



		-
5)	Control Box Suit	* 1
6	Handset	* 1
7	Wires	* 3



Ready To Use

Before Plugging the table into the outlet, make sure that - The lift columns are level and set at the lowest position. - All the screws are tightened, to avoid the desk making noise and wobbling. Activate the desk by following the next steps. 66.6 -Please press button down and hold for 10-15 seconds until it stutters and beeps. -Release the button, then your desk is ready to use.

Operation Guide

1. Memory desired height -Press button "M",display show "S-" with flash.

-Press number and set desired position.

2. Advanced Safety feature- lock and unlock the table.

- -Press button up and down at same time for 5 seconds, display "LOC"
- -All single button will be inactive and table will be unable to move.

-Pressing button up and down together willunlock the keypad and release the LOC

3. Reset the table

- When display show Error code or RST, Please reset the table.
- -Unplug the power cord from the control box.
- -Unplug the cable that links the keypad to the control box.
- -Wait 30 minutes and plug all the cables in again.

-Do the reset: please press button down and hold for 10-15 seconds until it stutters and beeps.

If the keypad displays HOT, please unplug and replug

and let it cool off for a couple of minutes before proceeding again.



Assembly Instruction






LOC M

10-15 seconds

-Office Desk -Electric lifting table




Installation tips



Please don't tighten the screws completely and go back later for a final tightening of all the screws after pieces are aligned with each other.


Lay a mat or used blanket out to assemble onto so the floor and the furniture doesn't get scratched or damaged during installation.


STEP 1:




1	Lift Column	* 2
3	Base	* 2
8	Leveling Studs	* 4
B	M6×16 Screws	* 8

STEP 3:











STEP 2:





2	Crossbar End Suit	* 1
A	M6×12 Screws	* 4

STEP 4:

